

Mercedes-Benz

AP00.20-U-1208GC

SERVICE SHEET for Mercedes-Benz Maintenance System (USA)

MODEL 164

except AMG and diesel models

Light Truck Model Year 2007

Model 164



| Customer: | | Repair order numl | ber: |
|---|--|-----------------------|---------------------------------|
| First visit | at 1,000 - 3,000 miles | Performed | YES NO |
| Tire Rotation | Performed in accordance with the tire manufacturer's recommended intervals | Tires rotated | YES NO |
| Tire Inspection | Inspect tires for damage and correct tire inflation pressure | Tires inspected | YES NO |
| Current mileage reading: | | Oil grade/viscosity | /: |
| Additional notes: | | | |
| | | | |
| | | | |
| | | | |
| Service work to be performe service advisor: | d as advised by Completion date: | Confirm wor below: | k has been performed by signing |

i

US Service 4 through US Service 20 apply to "Additional work" items only. Vehicle determines need for US Service 3 (Engine oil and filter change) as well as US Service 1 or US Service 2 Perform service necessary as indicated in display of instrument cluster only.

Perform each service as described.

| US Service | | first at 13,000 mi or 1 year; | after first every 26,000 mi or 2 years | |
|------------|------------|---|--|------------------|
| 1 | US Service | first at 26,000 mi or 2 years; | after first every 26,000 mi or 2 years | |
| L L | 2 ↓ | | Not OK ↓ | |
| | | Interior - Required | · · · | |
| | 0 | Reset service indicator in instrument cluster | | AP00.20-P-0042GZ |
| | 0 | Check parking brake (function test only) | | AP42.00-P-4290BA |
| | É3 | Interior - Recommended | | |
| | | Function test | | |
| | 0 | Horn | | |
| | 0 | Warning/indicator lamps | | AP54.30-P-5451GA |
| | 0 | Illumination and interior lighting | | AP54.30-P-5453GA |
| | 0 | Windshield wipers, windshield washer system, headlamp cleaning system | | AP82.30-P-8252GZ |
| | 0 | Check seat belts and buckles for signs of ex- ternal damage and proper function | | AP91.40-P-9150GZ |
| | 0 | Battery (Main/starter/auxiliary) check condition using Midtronics battery tester. Attach Midtronics test report print out here | | AP54.10-U-5453A |
| | | Wheels, brakes - Required | | |
| | 0 | Check thickness of brake pads, front and rear | | AP42.10-P-4253A |
| | 0 | Correct tire inflation pressure and enter in bar or psi. LF RF LR RR bar/psi: | | AP40.15-P-4061A |
| Ţ | | Wheels, brakes - Recommended | | |
| | O O | Remove and fit wheels | | AP40.10-P-4050Z |
| | 0 | Inspect tires for damage and splits, measu- re tread depth, record in mm: LF RF LR RR outside | | AP40.10-P-4051Z |
| | | Underside of vehicle - Required | | |
| | 0 | Leakage - Major components Check for chafe marks, line routing, dama- ged components i In the event of leakage, determine cau- se and perform repair via separate work or- der | | AP00.20-P-0053GZ |
| | 0 | Inspect condition of driveshaft flexible discs | | |

| US Service | US Service | | | Not OK | |
|------------|------------------|---|-------------|-------------|-------------------|
| 1 ↓ | 2 ↓ | | | Ļ | |
| | 0 | Check front axle ball joints for play, check rubber boots | | | AP33.20-P-3353GZ |
| | 0 | Check rear axle ball joints for play, check rubber boots | | | AP35.20-P-3555GZ |
| | 0 | Inspect play of tie rod and and drag link joints, inspect rubber boots | | | AP46.00-P-4653GZ |
| Î C | | Vehicle front/rear - Recommended | | | |
| | 0 | Check wiper blade condition | | | AP82.30-P-8253G |
| | 0 | Check and correct headlamp setting | | | AP82.10-P-8260GZ |
| 6 | - | Trunk - Required | | | |
| | 0 | Correct inflation pressure in spare tire and enter in bar or psi. bar/psi: | | | AP40.15-P-4061A |
| | <u> </u> | Engine compartment - Required | | | |
| | 0 | Leakage - Major components Check for chafe marks, line routing, dama- ged components i In the event of leakage, determine cau- se and perform repair via separate work or- der | | | AP00.20-P-0053GZ |
| | 0 | Check catch, safety catch and hinges on en- gine hood for proper operation. | | | AP88.40-P-8851GZ |
| | 0 | Clean water drain in air/water duct | | | AP83.10-P-8339M |
| | | Check condition of poly-V-belt | | | |
| | 0 | Engine 113 | | | AP13.22-P-1352GZ |
| | 0 | Engine 272, 273 | | | AP13.22-P-1352GZC |
| | | Check fluid level, correct as required i If there is a loss of fluid, determine cau- se and perform repair via separate work or- der | | | |
| | 0 | Brake system | | | AP42.10-P-4210GZ |
| | 0 | Power steering | | | AP46.00-P-4611GZ |
| | 0 | Windshield washer system (incl. summer/winter cleanser) | | | AP82.35-P-8210GZ |
| | | Additional Work | | | |
| Co | ompleted ⊠ ↓ | | | Not OK ↓ | |
| | rvice 3 uired | every 13,000 mi or 1 year: Engine compartment | | | |
| | | Engine - oil and filter change | Engine 113: | | AP18.00-P-0101RT |
| | | | Engine 272: | | AP18.00-P-0101PIT |
| | | | Engine 273: | | AP18.00-P-0101RX |

| Completed 🖂 | | | Not OK | |
|-----------------------------|--|-----------------------|--------|-------------------|
| ↓ US Service 4 | every 2 years: | | Ļ | |
| Required | Engine compartment | | | |
| | Replace brake fluid | | | AP42.00-P-4280GZ |
| US Service 4 Recommended | every 2 years: | | | |
| | Check bodywork for paint work damage by service advisor | | | AP98.00-P-9850GZ |
| | Underside of vehicle | | | |
| | Chassis and load-bearing body compo- nents: Check for damage and corrosion by service advisor | | | AP00.20-P-0090SX |
| US Service 5 Required | every 26,000 mi or 2 years: Passenger compartment | | | |
| | Replace combination filter CODE 581 (Comfort automatic air condi- tioning) | | | AP83.00-P-8384GZ |
| US Service 6 and 7 | not applicable | | | |
| US Service 8 Required | every 52,000 mi or 4 years: Engine compartment | | | |
| | Replace engine air-cleaner insert | Engine 113: | | AP09.10-P-0980GZ |
| | | Engine 272, 273: | | AP09.10-P-0980GZC |
| US Service 9 and 10 | not applicable | | | |
| US Service 11 Required | every 143,000 mi or 15 years: Passenger compartment | | | |
| | Replace fuel filter | Engines 272, 273, 113 | | AP47.20-P-0780GZ |
| US Service 12 Required | every 91,000 mi or 5 years: Engine compartment | | | |
| | Replace spark plugs | Engine 113: | | AP15.10-P-1580GZ |
| | | Engine 272, 273: | | AP15.10-P-1580GZC |
| US Service 13 Required | every 143,000 mi or 15 years: Engine compartment | | | |
| | Replace coolant | | | AP20.00-P-2080GZ |
| US Service 14 - 19 | not applicable | | | |
| US Service 20 Required | once at 39,000 mi: Underside of vehicle | | | |
| | Automatic transmission - oil and filter change | | | AP27.00-P-2702W |